


2'-6" CURB AND GUTTER



TRANSVERSE EXPANSION JOINT IN CURB AND GUTTER

GENERAL NOTES:

ALL CURB AND GUTTERS ARE TO BE POURED WITH CLASS "A" CONCRETE. (3000 PSI)

FLEXIBLE FORMS ARE TO BE USED WHEN RADII IS LESS THAN 200'.

CONTRACTION JOINTS SHALL BE SPACED AT 10' INTERVALS, EXCEPT THAT A 15' SPACING MAY BE USED WHEN A MACHINE IS USED OR WHEN SATISFACTORY SUPPORT FOR THE FACE FORM CAN BE OBTAINED WITHOUT THE USE OF TEMPLATES AT 10' INTERVALS. JOINT SPACING MAY BE ALTERED BY THE ENGINEER TO PREVENT UNCONTROLLED CRACKING.

CONTRACTION JOINTS MAY BE INSTALLED BY THE USE OF TEMPLATES OR FORMED BY OTHER APPROVED METHODS. WHERE SUCH JOINTS ARE NOT FORMED BY TEMPLATES, A MINIMUM DEPTH OF 1 1/2" SHALL BE OBTAINED.

ALL EXPANSION JOINTS SHALL BE FILLED WITH JOINT FILLER AND SEALED.

EXPANSION JOINTS SHALL BE SPACED AT 90' MAX. INTERVALS AND ADJACENT TO ALL RIGID OBJECTS (I.E.: EXISTING DRIVEWAYS, CURB & GUTTER, SIDEWALK, ETC.).

STANDARD 30" CURB & GUTTER CROSS-SECTION

REVISIONS		
NO	DATE	DESCRIPTION

CITY OF ROCKY MOUNT
DEPT. OF ENGINEERING

APPROVED
-
DATE
09-24-08

STD. NO.
2.4
REVISION
-